



# Service Manual

## Proportioning Unit

### Easy Spray

Issue 3.5 22/09/23  
Ref. NR-00019-ENG



***Before installing the unit and starting it up, read all the technical and safety documentation included in this manual carefully. Pay special attention to the information to know and understand the operation and the conditions of use of the unit. All of the information is aimed at enhancing User Safety and avoiding possible breakdowns derived from the incorrect use of the unit.***



## WARRANTY

HI-TECH SPRAY EQUIPMENT, S. A. (hereinafter "HI-TECH") grants this Limited Guarantee to the original buyer (hereinafter the "Client") for the unit and the original accessories given with the unit (hereinafter the "Product") against any fault in the design, materials or manufacture of the Product at the time of the first purchase by the user and for a duration of two (2) years thereafter.

If during the guarantee period and under normal conditions of use, the Product should fail to work correctly due to defects of design, material or manufacture, the authorised distributor of the country where the HI-TECH Product or technical assistance service has been purchased shall repair or replace the Product in accordance with what is established in the following:

### CONDITIONS

- a) The validity of this guarantee will be subject to the presentation of the original invoice issued by the HI-TECH authorised distributor for the sale of the Product along with the Product handed over for repair or replacement, which must show the date of purchase and the serial number. HI-TECH reserves the right to refuse to give the guarantee service when the indicated data fail to appear on the invoice or have been modified after the purchase of the Product.
- b) The repaired or replaced Product will continue to maintain the original guarantee for the time remaining until the end of the guarantee or for three (3) months from the repair date, if the remaining period of the original guarantee were shorter.
- c) This guarantee will not be applied to the faults in the Product caused by its faulty installation, the natural wear and tear of the components, any use other than that considered normal for this Product or which should fail to strictly comply with the instructions of use provided by HI-TECH; due to accident, carelessness, adjustments, alterations or modifications of the Product not authorised by HI-TECH or due to the use of accessories, heating devices, pumping equipment and/or dispensers that have not been approved or manufactured by HI-TECH.
- d) The guarantee applicable to the components and accessories forming part of the Product and which have not been made by HI-TECH will be limited to the guarantee offered by the original manufacturer thereof.

**HI-TECH WILL NOT RECOGNISE ANY EXPRESS ORAL OR WRITTEN GUARANTEES OTHER THAN THIS PRINTED LIMITED GUARANTEE. ALL IMPLICIT GUARANTEES, INCLUDING, WITHOUT LIMIT, ADAPTATION FOR A SPECIFIC USE, ARE SUBJECT TO THE DURATION OF THIS WRITTEN GUARANTEE. HI-TECH DOES NOT ASSUME ANY KIND OF COMMITMENT OR RESPONSIBILITY FOR ALL POSSIBLE DAMAGE OR EXPENSE CAUSED BY FAULTS IN THE OUTPUT OF THE PRODUCT, ITS WORKING OR THE DISPENSING OF MATERIAL THROUGH THE PRODUCT, INCLUDING, WITHOUT LIMITATION, ALL EXPENSES CAUSED BY DAMAGE TO PEOPLE OR PROPERTY. EQUALLY, HI-TECH WILL IN NO CASE ACCEPT LIABILITY FOR THE LOSS OF SPECULATIVE PROFITS OR COMMERCIAL LOSSES. ALL REPAIRS OR REPLACEMENT OF FAULTY PRODUCTS WILL CONSTITUTE THE COMPREHENSIVE FULFILMENT OF HI-TECH'S OBLIGATIONS WITH RESPECT TO THE CLIENT. HI-TECH DOES NOT IN ANY WAY GUARANTEE THE SUITABILITY OR APTITUDE OF ITS PRODUCT FOR ANY PARTICULAR PURPOSE OR APPLICATION.**

All information provided on components which have not been manufactured by HI-TECH and which is based on reports received from the original manufacturer, though considered precise and reliable, is provided without any guarantee or responsibility of any explicit or implicit kind.

All concession, sale or financial leasing of the Product by HI-TECH in no case explicitly or implicitly constitutes any authorisation, acceptance or concession for the use of any rights or patents, nor does it encourage, nurture or back their infringement.

The restrictions on the guarantee suppose no limitation on the legal rights of the consumer established in applicable national legislation, nor do they affect any rights derived from the bargain and sale agreement between the consumer and supplier.



All information provided in this manual has been included in the confidence that it is true, although it does not constitute any responsibility or implicit or explicit guarantee. HI-TECH reserves the right at any time and without prior warning to make all improvements and modifications necessary to this manual, in order to rectify any possible typographical errors, increase the information contained or insert the changes caused to the characteristics and performance of the unit.

## SAFETY AND HANDLING

The equipment described in this manual has been designed and manufactured in compliance with the following European Directives, following as application guide the harmonized standards detailed and in conformity with the relevant UK Statutory Instruments (and their amendments):



### **Directive 2006/42/EC on machinery (UK Supply of Machinery (Safety) Regulations 2008)**

UNE EN 12100:2012 (BS EN ISO 12100:2010)

### **Directive 2014/30/EU on electromagnetic compatibility (UK Electromagnetic Compatibility Regulations 2016)**

UNE EN 55011 (BS UNE EN 55011)

UNE EN 55016-2-1 (BS UNE EN 55016-2-1); UNE EN 55016-2-3 (BS UNE EN 55016-2-3);  
UNE EN 55032 (BS UNE EN 55032)

UNE EN 61000-3-2 (BS UNE EN 61000-3-2); UNE EN 61000-3-3 (BS UNE EN 61000-3-3);  
UNE EN 61000-4-2 (BS UNE EN 61000-4-2); UNE EN 61000-4-3 (BS UNE EN 61000-4-3);  
UNE EN 61000-4-4 (BS UNE EN 61000-4-4); UNE EN 61000-4-5 (BS UNE EN 61000-4-5);  
UNE EN 6100-4-6 (BS UNE EN 6100-4-6); UNE EN 61000-4-8 (BS UNE EN 61000-4-8); UNE  
EN 61000-4-11 (BS UNE EN 61000-4-11)

### **Directive 2014/68/EU on pressure equipment (UK Pressure Equipment (Safety) Regulations 2016)**

UNE EN 809:1999 +A1 (BS EN 809:1998 +A1:2009)

### **Directive 2014/35/EU on electrical safety (UK Electrical Equipment (Safety) Regulations 2016)**

UNE EN 60204-1:2019 (BS EN 60204-1:2018)


### **Directive 2003/10/EC on noise level (UK The Control of Noise at Work Regulations 2005)**

UNE EN ISO 3740 (BS EN ISO 3740:2019)

UNE EN ISO 3746 (BS EN ISO 3746:2010)

### **Directive 2011/65/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment with amendment 2015/863/EU (UK The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012)**

### **Directive 2012/19/EU on waste electrical and electronic equipment (UK The Waste Electrical and Electronic Equipment Regulations 2013)**



Electrical products cannot be thrown out with the rubbish. They must be taken to a dedicated collection point for an environmentally sound disposal in accordance with local regulations. You must contact your local collective or retailer for information about recycling. Before leaving WEEE at appropriate collection facilities, batteries must be removed and disposed of separately for proper recycling. The packaging materials are recyclable. Dispose of packaging materials in an environmentally sound manner and place them at the disposal of recycling

sectors.

### TRANSPORT AND STORAGE

Proper precautions must be taken so that the equipment can withstand the effects of transport and storage temperatures between  $-25^{\circ}\text{C}$  and  $+55^{\circ}\text{C}$  or up to  $+70^{\circ}\text{C}$  for short periods that do not exceed 24 hours. Also, appropriate means to prevent damage from moisture, vibrations or shocks must be foreseen.

This chapter contains information on the safety, handling and use of the **Easy Spray** series proportioning unit.



***Before installing the unit and starting it up, read all the technical and safety documentation included in this manual carefully. Pay special attention to the information to know and understand the operation and the conditions of use of the unit. All of the information is aimed at enhancing User Safety and avoiding possible breakdowns derived from the incorrect use of the unit.***

***WARNING!*** establishes information to alert on a situation that might cause serious injuries if the instructions are not followed.

***CAUTION!*** establishes information that indicates how to avoid damage to the unit or how to avoid a situation that could cause minor injuries.

***NOTE:*** is relevant information on a procedure being carried out.

Careful study of this manual will enable the operator to know the characteristics of the unit and the operating procedures. By following the instructions and recommendations contained herein, you will reduce the potential risk of accidents in the installation, use or maintenance of the unit; you will provide a better opportunity for incident-free operation for a longer time, greater output and the possibility of detecting and resolving problems fast and simply.

Keep this Service Manual for future consultation of useful information at all times. If you lose this manual, ask for a new copy from your **HI-TECH** local distributor or directly contact **HI-TECH SPRAY EQUIPMENT, S.A.**

***WARNING!*** The design of the Easy Spray series proportioning unit does not allow its use in potentially explosive atmospheres or to exceed the pressure and temperature limits described in the technical specifications of this manual.



When working with the unit, it is recommended that the operator wear suitable clothing and elements of personal protection, including, without limitation, gloves, protective goggles, safety footwear and face masks. Use breathing equipment when working with the machine in enclosed spaces or in areas with insufficient ventilation. The introduction and follow-up of safety measures must not be limited to those described in this manual. Before starting up the machine, a comprehensive analysis must be made of the risks derived from the products to be dispensed, the type of application and the working environment.



***To prevent all possible bodily harm caused by incorrect handling of the raw materials and solvents used in the process, carefully read the safety information provided by your supplier.***

***Deal with the waste caused according to current regulations.***



***Disconnect the unit from the power supply before carrying out any operation inside the electrical console.***



***The electrical maintenance of the machine must only be performed by a qualified electrician.***



***To avoid damage caused by the impact of pressurized fluids, do not open any connection or perform maintenance work on components subject to pressure until the pressure has been completely eliminated.***



***Use suitable protection when operating, maintaining or remaining in the operating area of the unit. This includes, but is not limited to, the use of masks, protective goggles, gloves, shoes and safety clothing.***

***The unit includes components that reach temperatures that are liable to cause burns. The hot parts of the unit must not be handled until they have cooled.***

***To prevent serious harm by crushing or loss of limbs, do not work with the unit without the safety guards installed on all moving parts. Make sure that all of the safety protections are correctly reinstalled after all repair or maintenance work is completed.***

### CHARACTERISTICS

The **Easy Spray** proportioning unit has been designed and built for the application of Polyureas, chemical systems for polyurethane foaming, and some two-component Epoxy systems.


Its reduced size allows easy transport to site. Its easy operation (simply turn one switch and push the START button) reverts into time saving during set up and application.

#### Principal Heating System

Consists of two independent heaters without seals. Each heater has two 900 W heating elements, which give the unit a total power of 1800 W and the necessary control and safety components for the precise operation of the system. Its peculiar configuration allows a temperature differential ( $\Delta T$ ) of 30° C and application temperatures of up to 70° C under normal conditions of ambient temperature.

#### Proportioning Pumps

Comprises two positive displacement piston pumps, driven by a pneumatic motor. The system includes two pressure regulators that allow the working pressures to be equalized in the two directions of pump movement, compensating for the imbalance of pressure caused by the difference between the upper and the lower side of the air motor, and the effect of the additional pressure of the transfer pumps.






### Recirculation System

Allows keeping the products in temperature prior to start spraying and during breaks.

### Proportioning System (OPTIONAL)

Designed with a 2000 W isolation transformer that enables effective heating up to a total hose length of 48 meters (165 feet). The system includes an innovative hose heating concept in which the copper heating element is spread evenly around the circumference of the hose, providing a uniform heating watt density and precise control of the product application temperature.





## TECHNICAL SPECIFICATIONS EASY SPRAY-100

### Electrical

Main Voltage: \_\_\_\_\_ 230 V  
Frequency: \_\_\_\_\_ 50/60 Hz  
Electrical Consumption: \_\_\_\_\_ 16 A @ 1NPE~230V  
@ 3NPE~400V  
Total Active Power: \_\_\_\_\_ 3.6 kW  
Heater Power: \_\_\_\_\_ (2 x 1.8 kW) 3.6 kW  
Transformer Frequency (Optional): \_\_\_\_\_ 50/60 Hz  
Transformer Active Power (Optional): \_\_\_\_\_ 1,6 kW  
Transformer Electrical Consumption (Optional): \_\_\_\_\_ 9 A @ 1NPE~230V  
@ 3NPE~400V


### Mechanical

Maximum Working Pressure (air supply 9 bar): \_\_\_\_\_ 100 bar (10 MPa)  
Maximum Production Ratio 1:1: \_\_\_\_\_ 4 kg/min  
Minimum Production: \_\_\_\_\_ 1 kg/min  
Recirculation Hose Length: \_\_\_\_\_ 11 m  
Maximum Heated Hose Length (Optional): \_\_\_\_\_ 48 m  
Approximate Air Consumption @ 6 bar: \_\_\_\_\_ 550 l/min  
Recommended Compressor: \_\_\_\_\_ 5,5 HP three-phase  
Approximate weight without Transformer (standard version): \_\_\_\_\_ 92 kg  
Approximate weight with Transformer (optional version): \_\_\_\_\_ 112 kg  
Dimensions: \_\_\_\_\_ H: 1000 mm / A: 610 mm / L: 700 mm

### Acoustic

A-weighted sound pressure level: \_\_\_\_\_ 74,2 dB (A)  
A-weighted sound power level: \_\_\_\_\_ 88,6 dB (A)

**Values obtained according to UNE-EN ISO 3746:1995 standard.**





## GENERAL DESCRIPTION




Figure 1. General Description Easy Spray



### **1. Isocyanate Tank**

Contains the A chemical element. Capacity 30 liters.

### **2. Polyol Tank**

Contains the R chemical element. Capacity 30 liters.

### **3. Isocyanate Recirculation Valve**

Allows selecting recirculation or spraying in the Isocyanate circuit.

### **4. Polyol Recirculation Valve**

Allows selecting recirculation or spraying in the Polyol circuit.

### **5. Control Panel**

Controls and regulates the correct operation of the unit.

### **6. Isocyanate Proportioning Pump**

Meters the Isocyanate.

### **7. Polyol Proportioning Pump**

Meters the Polyol.

### **8. Isocyanate Heater**

Heats the Isocyanate to the pre-set temperature.

### **9. Polyol Heater**

Heats the Polyol to the pre-set temperature.

### **10. Hose Heating Transformer (Optional)**

Supplies the required voltage for heating the hoses.

### **11. Hose Electrical Regulator (Optional)**

Set the electric power desired for heating the hoses.

### **12. Downstroke Pressure Gauge**

Indicates the pneumatic pressure on the downstroke of the motor.

### **13. Upstroke Pressure Gauge**

Indicates the pneumatic pressure on the upstroke of the motor.

### **14. Isocyanate Heater Probe**

Provides information on the temperature of the Isocyanate

### **15. Polyol Heater Probe**

Provides information on the temperature of the Polyol.

### **16. Isocyanate Inlet Filter**

Avoids the penetration of solid particles inside the Isocyanate pump of the unit.

### **17. Polyol Inlet Filter**

Avoids the penetration of solid particles inside the Polyol pump of the unit.

### **18. Main Pneumatic Valve**

It opens and closes the flow of air coming into the pneumatic system.

### **19. Retract Valve**

Sets the piston rod of the Isocyanate proportioning pump to the retract position and prevents the crystallization of Isocyanate on the piston rod. Close the RETRACT valve every time the unit is stopped by the operator.

### **20, 21. Air motor pressure regulators**

Using the two air pressure regulators, select the pressure for the down stroke (20, LH) and the up stroke (21, RH) of the pneumatic cylinder.




**22. Isocyanate Circuit Safety Pressure Switch**

Deactivates the safety solenoid valve in case of excess pressure in the isocyanate circuit.

**23. Polyol Circuit Safety Pressure Switch**

Deactivates the safety solenoid valve in case of excess pressure in the polyol circuit.

## CONTROL PANEL AND HOSE HEATED SYSTEM



**Figure 2. Control Panel and Hose Heating**

Comprises two electrical components for an accurate working of the unit.

### 1. Main Power Switch

Turns the electric supply to the control panel on and off. It must be turned ON for any operation to be performed with the unit.

### 2. Start Button

This pushbutton turns the circuit control on.

### 3. ISO/POL Temperature Regulator

Establishes the temperature needed for every product.

### Note:

To manipulate the device, refer to the specific chapter “Regulator of Temperature Heaters”.




### 4. Hoses (OPTIONAL)

Hose heating is activated and deactivated by the orange pushbutton located at the front of the transformer. It will lit up when heating is activated.

Turn the potentiometer clockwise to increase amps, and anti-clockwise if you wish to decrease amps. Adjustment ranges from 0 to 50 amps.

Take the values below as an approximate reference to select the intensity that allows reaching the requested application temperature.



30 A	38° C	100° F
35 A	48° C	118° F
40 A	60° C	140° F
45 A	75° C	167° F
50 A	80° C	176° F

Turn the potentiometer clockwise until the screen shows the required amps for a quick pre-heating.

**NOTE:** The circuit breaker software of the transformer has a safety system to prevent the hoses from being exposed to high temperatures during long periods of time.

*If you have selected a potential over 35 amperes, after 20 minutes, the potential will automatically regulate to 35 amperes.*

*This potential cannot be set above 35 amperes until the heater is disconnected from the hoses and reconnected.*

### 5. Heaters Switch

Turns the electric supply to the control heaters unit ON and OFF.



## REGULATOR OF TEMPERATURE HEATERS

This machine equips each heater with separate temperature regulators.

### Instructions

When the power is connected to the machine, the displays will show the current temperature values.

To modify the values press ▲ or ▼ as required.

For more details about the settings, follow the instructions from the manufacturer's manual attached.



#### Step 1 : Enter the protection level.

Press the number keys 1 and 2 for at least 3 seconds. (+ de 3 segundos)

Press the number key 2 for advance, press the number key 4 or 5 to change the parameter.

Input parameters:

- PMoV = 0
- oAPt = 0 unblocked
- iCPt = 1 unblocked
- WtPt = oFF
- PFPt = oFF
- CHGP = oFF
- PMSK = oN
- PRLP = 0

To exit the protection level press the number keys 1 and 2 for at least 3 seconds. (+ de 3 segundos)

#### Step 2 : Input parameters.

Press the number key 1 for at least 3 seconds. (+ de 3 segundos)

Press the number key 2 for advance, press the number key 4 or 5 to change the parameter.

Factory parameters. iN-t = 0 (Sheet 3)

- d-U = C
- SL-H = 90
- SL-L = 0
- CNtL = Pid
- S-HC = StNd
- St = oN
- PtRN = oFF
- CP = 20
- oREV = oR-R
- Alt1 = 0
- Alt2 = 0
- Alt3 = 0

To exit the level of input parameters press the number key 1 for at least 3 seconds. (+ de 3 segundos)



### Step 3 : Entry level adjustment parameters.

Press the number key 1 less than 1 second. (- de 1 segundo)

Press the number key 2 for advance, press the number key 4 or 5 to change the parameter.

Factory parameters. L.Adj = 3001

A† = oFF

iNS = 0.0

iNR† = 1.000

P = 9.0

i = 260

d = 45

To exit the level adjustment parameters press the number key 1 less than 1 seconds. (- de 1 segundo)

### Step 4 ; Enter the protection level.

Restricts which settings can be displayed or changed, and restricts change by key operation.

Press the number keys 1 and 2 for at least 3 seconds. (+ de 3 segundos)

Press the number key 2 for advance, press the number key 4 or 5 to change the parameter.

Factory parameters: PMoV = 0

oAP† = 2 blocked

iCP† = 2 blocked

WtPt = oFF

PFP† = oFF

CHGP = oFF

PMSK = oN

PRLP = 0

To exit the protection level press the number keys 1 and 2 for at least 3 seconds. (+ de 3 segundos)

### Step 5 : To change the setpoint to press number key 5 to increase the value, or the number key 4 to download.



Input type	Sensor type	Input temperature setting range in °C	Input temperature setting range in °F	E5CC/E5EC set value
Resistance thermometer	Pt100	–200 to 850 °C	–300 to 1500 °F	0
		–199.9 to 500.0 °C	–199.9 to 900.0 °F	1
		0.0 to 100.0 °C	0.0 to 210.0 °F	2
	JPt100	–199.9 to 500.0 °C	–199.9 to 900.0 °F	3
		0.0 to 100.0 °C	0.0 to 210.0 °F	4
Thermocouple	K	–200 to 1300 °C	–300 to 2300 °F	5 (default)
		–20.0 to 500.0 °C	0.0 to 900.0 °F	6
	J	–100 to 850 °C	–100 to 1500 °F	7
		–20.0 to 400.0 °C	0.0 to 750.0 °F	8
	T	–200 to 400 °C	–300 to 700 °F	9
		–199.9 to 400.0 °C	–199.9 to 700.0 °F	10
	E	–200 to 600 °C	–300 to 1100 °F	11
	L	–100 to 850 °C	–100 to 1500 °F	12
	U	–200 to 400 °C	–300 to 700 °F	13
		–199.9 to 400.0 °C	–199.9 to 700.0 °F	14
	N	–200 to 1300 °C	–300 to 2300 °F	15
	R	0 to 1700 °C	0 to 3000 °F	16
	S	0 to 1700 °C	0 to 3000 °F	17
	B	100 to 1800 °C	300 to 3200 °F	18
	W	0 to 2300 °C	0 to 3200 °F	19
	PLII	0 to 1300 °C	0 to 2300 °F	20

Any value can be set for any model.


**NB:** The temperature regulators are not inter-changeable with those attached to previous versions of the machine

## METHOD OF THREADED UNION OF THE HOSES



Follow the torques for threaded joints listed in **Table 1** according to thread sizes of hose fittings to ensure their proper assembly.

There is also an alternative procedure to obtain an equivalent torque without using special tools: joint both ends of the hoses to be connected, tighten a swivel nut by hand (without using spanner) until there is resistance on the nut. Fit two spanners (1) on the fixed ends of the hoses and turn the swivel nut with a third spanner (2) as many flats from wrench resistance (FFWR) as indicated in **Table 1**.

Table 1. Tightening Threaded Joints		
THREAD SIZE	TORQUE Nm	FFWR
1/2"-20	23	2 (or 120°)
9/16"-18	30	1-1/2 (or 90°)



**NOTE:** 1 FFWR corresponds to one complete shear of a flat marked with red between swivel and fitting or else 60°.





## GENERIC INSTALLATION

**CAUTION!** Use suitable protection and follow the recommendations in the safety information provided by product suppliers when installing or working with the unit.


HI-TECH provides a set of tools and accessories necessary for the assembly of the machine. The set is composed of the following elements:

Item	DESCRIPTION	QTY.
BI-00009	Lithium Grease Tube 50 gr	1x
HT-00001	Magnet holder tool	1x
NR-00018	Parts Manual	1x
NR-00019	Service Manual	1x
NR-00045	Vertical Pumps Manual	1x
<b>OPTIONAL</b>		
MA-00102	12" Hose Connections Protector	2x
EL-00093-01	White Flange 300 x 4.8	3x
HT-00045	Allen 1/8"	1x
EL-00100-06	Blue Terminal Cable 16 mm <sup>2</sup> L=12mm	2x
TN-00242	Threaded Rod 1/4"-20 UNC x 14" nylon	2x
NR-00093	Recirculation Kits Manual	1x

**NOTE:** To ensure that the unit works correctly, the electrical supply must meet the specifications indicated on page six of this manual and appearing on the machine specifications plate.

Use the proper size of cable according to the voltage, current and maximum power required by the Unit.


*The dimensioning of the cable is calculated for a length of 25m, for longer lengths you must recalculate the appropriate section.*



## INSTALLATION (RECIRCULATION UNIT)


Follow the recommended procedure in the indicated order to install the unit:

- Fill the Isocyanate pump lubricating cup with DOTP plasticizer.
- Connect the pressure hose of each product to the outlet of the respective heaters (the Isocyanate hose to the Isocyanate heater and the Polyol hose to the Polyol heater).
- Connect the recirculation hose of each product to the recirculation valves located in the ISO or POLY tank. (the Isocyanate hose to the Isocyanate tank valve and the same in the Polyol side).



**ISO LUBRIFICATION CUP**

**NOTE:** The product hoses have been identified with red (Isocyanate) and blue (Polyol), enabling them to be rapidly distinguished. To avoid errors in connecting the coupling connectors of the Isocyanate and Polyol hoses, the connectors are of different sizes to make it impossible for connections to be swapped.



**Figure 3. Method of union of the Hoses**

**WARNING!** To join the hoses together or to connect them to the heaters or the gun, use two spanners to hold the parts to be joined (1) and a third spanner to tighten or loosen the connecting nut (2) as shown in the illustrations in Figure 3 on page 20. The connections must be tightened to a torque of Table 1 in pg. 18.



- d) Connect the air hoses.
- e) Connect the two pressure hoses to the connectors of the coupling block of the gun, making sure that the manual valves are closed. (the Polyol hose to the Polyol connector and the Isocyanate hose to the Isocyanate connector).
- f) Connect the recirculation hoses to the connectors of the coupling block of the gun.
- g) Insert a contact thermometer through the hose insulation so that the bottom of the thermometer is in contact with the hoses and the top is outside the insulation. Fit the thermometer in such a way that the operators can see the temperature when they are spraying.
- h) Fill the Isocyanate and Polyol tank.

### **WARNING!**

***To prevent possible bodily harm caused by incorrect handling of the raw materials and solvents used in the process, carefully read the safety information provided by your supplier.***

***To avoid splashing, open only the lid of the tank (Isocyanate or Polyol) where the product will be poured.***

***Never change the chemical components, use always the same tank for each component.***

### **WARNING!**

***In order to avoid product contamination, make sure that the tanks are well closed.***



***Do not fill the tank to maximum capacity; check the level on the tank to make sure that 20% of its maximum capacity is vacant. Each tank is 30 liters.***

***Small vessels (10-15 liters maximum) are recommended to pour the product inside the tanks.***


***Fill the tanks with the amount of product required for each application.***

Before using the unit, the retained air and the residual oil from the operating tests made in the factory must be eliminated. To purge the whole circuit, proceed as follows:

- a) Remove the recirculation hoses and place them in two separate vessels to gather up the products contained inside the machine.
- b) Open the manual valves at the bottom of the tanks.
- c) Open the manual recirculation valves.
- d) Turn the "RETRACT" valve as it appears (in vertical position it's opened).
- e) Turn the general switch "ON".
- f) Turn the air pressure regulators anti-clockwise until the end.



- g) Push the “START” green button. The temperature regulator displays will light on, (whenever the switch of the heaters is in “On”). Check the product pumps begin to move slowly.  
If necessary, increase the pneumatic pressure by turning the regulator clockwise until the product pumps begin to move slowly.
- h) Allow the materials to come out of the recirculation hose until the residual oil and the air bubbling has disappeared completely.
- i) Close the product recirculation valves.
- j) Clean the recirculation hoses and place them to their tanks again.
- k) Slowly increase the pneumatic pressure to check for product leaks in the hose connections.
- l) Close the “RETRATC” valve (horizontal position).
- m) Turn the general switch “OFF”. The temperature regulator displays will go out. The machine is ready.



**RETRACT  
VALVE**



## START-UP PROCEDURES

Follow the recommended procedure in the indicated order.

**CAUTION!** *The start-up procedures assume that all of the necessary adjustments have been correctly performed.*

- a) Check the state of the DOTP plasticizer in the Isocyanate pump lubrication cup. Change the oil if you see changes in the color or signs of solidification and retighten the packing nut to ensure the seal.
- b) Make sure the chemical tanks are full of material.
- c) Check the inlet filters of the products. Clean them if necessary.
- d) Open the product manual valves at the bottom of the tanks.
- e) Open the manual recirculation valves.

**NOTE:** *Do this if you're willing to recirculate products.*

**NOTE:** *Product recirculation allows reaching the set up temperature in the heaters quicker, heating the hoses and the gun at the same time. For more effectiveness for heating the products whilst recirculating, fill the product tanks with the minimum quantity required.*

**CAUTION!** *Product tanks are made of a plastic material which resists up to 80 °C. Product temperature inside the tanks must never reach that limit.*

**CAUTION!** *Do not recirculate with full tanks, since over pressure may occur in the interior of the tanks.*

- f) Turn the general switch "ON".
- g) Open the "RETRATC" valve, (vertical position).
- h) Push the "START" green button. The temperature regulator displays will light on, (whenever the switch of the heaters is in "On"). Check the product pumps begin to move slowly.
- i) Using the air pressure regulators, first of all select the pressure for the down stroke of the proportioning pumps and then adjust the pressure for the up stroke. The pressures must be practically the same and remain constant.
- j) If the pressures fluctuate on each stroke, check the troubleshooting section before continuing.
- k) Set the temperature on the Isocyanate Regulator
- l) Set the temperature on the Polyol Regulator.
- m) Connect the air supply to the gun.
- n) Close the recirculation valves; should these be open, open the manual gun valves of each product; make a test projection and check the pressures on the product gauges. If the projection test is correct and the pressures remain equal, proceed with the application.



## DAILY SHUTDOWN

Follow the recommended procedure in the indicated order for machine shut down when work is stopped for the day.

- a) Close the "RETRACT" valve, (horizontal position).
- b) Close the manual valves at the bottom of the tanks.
- c) Use the gun to project into a waste container until the Isocyanate proportioning pump is in the retract position and the pressure begins to fall.

**CAUTION!** *To avoid possible product leakage and early failure of the pump seals, the pressure must not be reduced to zero. It is recommended to keep the system with a minimum pressure of 30 bar (400 psi) to extend the life of the seals.*

- d) Turn the general switch "OFF". The temperature regulator displays will then go out.
- e) Close the manual valves on the coupling block and dismantle the gun to perform the corresponding maintenance.



## CLEANING

**CAUTION!** *The unit includes components that reach temperatures that are liable to cause burns. The hot parts of the unit must not be handled until they have cooled.*

To avoid possible contamination, the circuits of the unit must be flushed clean (pumps, heaters and hoses) whenever applications have to be made that require a change of components.

Follow the recommended procedures in the order indicated to perform the cleaning:

- a) Remove the recirculation hoses and place them in two separate vessels to gather up the products contained inside the machine.

**NOTE:** *Should the products be used again, use a proper vessel to store them, following the instructions from your product supplier.*

- b) Open the manual valves at the bottom of the tanks.
- c) Open the manual recirculation valves.
- d) Open the "RETRACT" valve, (vertical position).
- e) Turn the general switch "ON".
- f) Turn the air pressure regulator anti-clockwise until the end.
- g) Push the "START" green button. The temperature regulator displays will light on, (whenever the switch of the heaters is in "On"). Check the product pumps begin to move slowly.  
If necessary, increase the pneumatic pressure by turning the regulator clockwise until the product pumps begin to move slowly.
- h) Allow the materials to come out of the recirculation hose until the tanks are completely empty.
- i) Turn the general switch "OFF". The temperature regulator displays will then go out.
- j) Close the product manual valves at the bottom of the tanks.
- k) Fill the component tanks using DOTP cleaning agent (about 5 liters in each tank).
- l) Open the product manual valves at the bottom of the tanks.
- m) Place the recirculation hoses to their tanks again and make sure the recirculation valves are open.
- n) Dismantle the gun and leave the coupling block connected to the hoses. Make sure the gun valves are closed.
- o) Turn the general switch "ON".
- p) Push the "START" button. The temperature regulator displays will light on, (whenever the switch of the heaters is in "On"). Check that the product pumps move.
- q) Maintain the unit recirculating for about 2-3 minutes to clean the hoses and the tanks. For a more efficient cleaning of the tanks, the cleaning agent can be heated through the heaters.
- r) Turn the general switch "OFF". The temperature regulator displays will then go out.
- s) Remove the recirculation hoses of the Isocyanate and Polyol tanks again and place them in two separate waste vessels.
- t) Turn "off" the "heaters" switch.



- u) Turn the general switch "ON".
- v) Push the "START" green button, the temperature regulator not will light on. Check the product pumps begin to slowly move.
- w) Allow the materials to come out of the recirculating hoses until the tanks are empty.
- x) Turn the general switch "OFF".
- y) Close the manual valves at the bottom of the tanks.
- z) Close the recirculation manual valves.
- aa) Fill the product tanks with new product.
- bb) Open the manual valves at the bottom of the tanks.
- cc) Open the recirculation manual valves.
- dd) Turn the general switch "ON".
- ee) Push the "START" green button. The temperature regulator displays not will light on. Check the product pumps begin to move slowly.  
If necessary, increase the pneumatic pressure by turning the regulator clockwise until the product pumps begin to move slowly.
- ff) Allow the DOTP agent to come out of the recirculation hose until see the new product.
- gg) Allow the products to come out until you see that only DOTP cleaning agent comes out free of impurities.
- hh) Close the "RETRATC" valve (horizontal position).
- ii) Turn the general switch "OFF" and return to the position "On" the switch of the heaters.
- jj) Clean and move the recirculation hoses to the tanks again.
- kk) Close the manual valves at the bottom of the tanks.
- ll) The cleaning process is complete and you can proceed as normal for new products.



## SHUTDOWN PROCEDURES

**CAUTION!** *The unit includes components that reach temperatures that are liable to cause burns. The hot parts of the unit must not be handled until they have cooled.*

When you plan to shut down the machine for more than FOUR weeks, the products contained in the machine must be replaced by DOTP plasticizing agent.

Follow the recommended procedures in the order indicated:

Remove the recirculation hoses and place them in two separate vessels to gather up the products contained inside the machine.

**NOTE:** *Should the products be used again, use a proper vessel to store them, following the instructions from your product supplier.*

- a) Open the manual valves at the bottom of the tanks.
- b) Open the manual recirculation valves.
- c) Open the "RETRACT" valve (vertical position).
- d) Turn the general switch "ON". Using the air pressure regulators, turn anti-clockwise until the end.
- e) Push the "START" green button. The temperature regulator displays will light on, (whenever the switch of the heaters is in "On"). Check the product pumps begin to move slowly.
- f) If necessary, increase the pneumatic pressure by turning the regulator clockwise until the product pumps begin to move slowly.
- g) Allow the materials to come out of the recirculation hose until the tanks are completely empty.
- h) Turn the general switch "OFF". The temperature regulator displays will then go out.
- i) Close the product manual valves at the bottom of the tanks.
- j) Fill the component tanks using DOTP cleaning agent (about 5 liters in each tank).
- k) Open the product manual valves at the bottom of the tanks.
- l) Place the recirculation hoses to their tanks again and make sure the recirculation valves are open.
- m) Dismantle the gun and leave the coupling block connected to the hoses. Make sure the gun valves are closed.
- n) Turn the general switch "ON".
- o) Push the "START" green button. The temperature regulator displays will light on, (whenever the switch of the heaters is in "On"). Check that the product pumps move.
- p) Maintain the unit recirculating for about 2-3 minutes to clean the hoses and the tanks. For a better cleaning of the tanks, the cleaning agent can be heated through the heaters.
- q) Turn the general switch "OFF". The temperature regulator displays will then go out.
- r) Remove the recirculation hoses again and place them in two separate vessels to gather up the products contained inside the machine.
- s) Turn the general switch "ON".



- t) Push the "START" green button, the temperature regulator will light on, (whenever the switch of the heaters is in "On"). Check the product pumps begin to slowly move.
- u) Allow the materials to come out of the recirculation hoses until the tanks are empty.
- v) Turn the general switch "OFF". The temperature regulator will go out.
- w) Close the manual valves at the bottom of the tanks.
- x) Close the recirculation manual valves.
- y) Move the recirculation hoses to the tanks again and make sure that the manual valves are open.
- z) Fill the component tanks using DOTP cleaning agent, about 5 liters in each tank.
- aa) Close the recirculation manual valves.
- bb) Turn the general switch "ON".
- cc) Push the "START" green button. The temperature regulator displays will light on, (whenever the switch of the heaters is in "On"). Check that the product pumps move.
- dd) Turn the general switch "OFF". The temperature regulator displays will then go out.
- ee) Close the "RETRACT" valve (horizontal position).
- ff) Reduce the pressure of the products by opening the recirculation valves in the tanks and closing them immediately after.

To avoid possible product leakage and the early failure of the pump seals, the pressure must not be reduced to zero. It is recommended to keep the system with a minimum pressure of 30 bar (400 psi) to extend the life of the seals.

***Never leave the machine or the hoses empty of product or DOTP plasticizing oil.***

***NOTE: Never use liquids not recommended or not approved by HI-TECH. Never use approved liquids that have been contaminated with water or ISO/POL. If you are not sure in the quality of the liquid you are going to use we strongly recommend that you check the machine 2-3 times every 2 weeks after you have filled it by recirculating through heated hoses (see p.34) and/or hoses with recirculation (see p.25) with fresh plasticizer unless you make sure the liquid that comes out is completely pure and clean.***



## INSTALLATION (HEATED HOSES UNIT)

Follow the recommended procedure in the indicated order to install the unit:

- Fill the Isocyanate pump lubricating cup with DOTP plasticizer.
- Connect the hoses of the products to the outlets of the respective heaters (the Isocyanate hose to the Isocyanate heater and the Polyol hose to the Polyol heater).


**NOTE:** The product hoses have been identified with red (Isocyanate) and blue (Polyol), enabling them to be rapidly distinguished. To avoid errors in connecting the coupling connectors of the Isocyanate and Polyol hoses, the connectors are of different sizes to make it impossible for connections to be swapped.

The hoses receive vacuum drying treatment and are supplied interconnected at the ends to prevent them from absorbing moisture. Do not separate them until they are going to be installed in the unit.

The hose connection system includes special terminals (fast lock) to facilitate the electrical connection to the transformer and between the different sections installed in the unit.

The transformer offers the option of connecting to a 40 V output voltage valid for a total hose length of up to 48 meters.

- Connect the heated hoses wires to the "fast lock" connector coming out of the hose transformers as follow:
  - Unscrew the Nylon Safety Plug from the "fast lock" connector body.
  - Unscrew partially the Socket Head Set Screw from electrical wires.
  - Insert the heated hose electrical wire with terminals into the "fast lock" connector body.
  - Tighten the Socket Head Set Screw of the terminals and place the Nylon Safety Plugs



Repeat the same steps to connect the "fast lock" that you will find in the middle hose connections.

- Connect the rest of the product hoses to complete the required length. Remember that the hoses are identified with red (Isocyanate) and blue (Polyol).

**WARNING!** To join the hoses together or to connect them to the heaters or the gun, use two spanners to hold the parts to be joined (1) and a third spanner to tighten or loosen the connecting nut (2) as shown in the illustrations in Figure 3 on page 20. The connections must be tightened to a torque of Table 1 in pg. 18.



**NOTE:** *Assure the proper mechanical and electrical connection of the hoses to avoid possible product leakage and hose heat problems.*

- c) Connect the air hoses.
- d) Connect the hoses to the connectors of the coupling block of the gun, making sure that the manual valves are closed.
- e) Insert a contact thermometer through the hose insulation so that the bottom of the thermometer is in contact with the hoses and the top is outside the insulation. Fit the thermometer in such a way that the operators can see the temperature when they are spraying. If the hoses have STC probes to automatically control the temperature, the contact thermometer will not have to be installed.
- f) Fill the Isocyanate and Polyol Tank

**WARNING!**

*To prevent possible bodily harm caused by incorrect handling of the raw materials and solvents used in the process, carefully read the safety information provided by your supplier.*

*To avoid splashing open only one tank Isocyanate or Polyol.*

*Never change the chemical components, use always the same tank for each component.*

*In order to avoid product contamination, make sure that the tanks are well closed.*

*Do not fill the tank to its maximum capacity; check the level on the tank to make sure that 20% of its maximum capacity is vacant. Each tank is 30 liters.*

*Small vessels (10-15 liters maximum) are recommended to pour the product inside the tanks.*

*Fill the tanks with the amount of product required for each application.*





Before using the unit, the retained air and the residual oil from the operating tests made in the factory must be eliminated. To purge the whole circuit, proceed as follows:

- a) Keep the coupling block with the outlet of each product in separate vessels and open the manual valves of each product.
- b) Turn the pneumatic pressure regulator counter clockwise as far as it will go.
- c) Open the manual valves at the bottom of the tanks.
- d) Turn the "RETRATC" valve as it appears (in vertical position it's opened).
- e) Turn the general switch "ON".
- f) Push the "START" green button. The temperature regulator displays will light on, (whenever the switch of the heaters is in "On"). Check the product pumps begin to slowly move.

Allow the materials to come out of the coupling block until the residual oil and the air bubbling has disappeared completely.

- g) Close the manual valves of each product and clean the coupling block of the remaining supply of product.
- h) Slowly increase the pneumatic pressure to check for product leaks in the hose connections. Retighten if necessary and tape the connectors to protect them from possible damage.
- i) Close the "RETRACT" valve (horizontal position).
- j) Turn the general switch "OFF". The temperature regulator will go out.
- k) Mount the gun on the coupling block.



## START UP PROCEDURES

Follow the recommended procedure in the indicated order.

**CAUTION!** *The start-up procedure assumes that all of the necessary adjustments have been correctly performed.*

- a) Check the state of the DOTP plasticizer in the Isocyanate pump lubrication cup. Change the oil if you see changes in the color or signs of solidification and retighten the packing nut to ensure the seal.
- b) Make sure the level of the chemical tanks is enough to process the system.
- c) Check the inlet filters of the products. Clean them if necessary.
- d) Open the manual valves at the bottom of the tanks.
- e) Turn the potentiometer located on the transformer to apply the electrical intensity to the heating hose system. (**See Amps table on page 14**).



***Selected intensity must not be maintained over 10 minutes. After that time, turn the potentiometer anti-clockwise until the screen shows 25amps.***

***To avoid excessive pressure in the heated hoses, wait for the product in them to reach the required temperature before starting up the air motor system.***

- f) Turn the general switch "ON".
- g) Open the "RETRATC" valve (vertical position).
- h) Push the "START" green button, the temperature regulator displays will light on, (whenever the switch of the heaters is in "On").
- i) Set the Isocyanate Temperature on the Iso Regulator.
- j) Set the Polyol Temperature on the Poly Regulator.
- k) Using the air pressure regulators, first of all select the pressure for the down stroke of the proportioning pumps and then adjust the pressure for the up stroke. The pressures must be practically the same and remain constant. If the pressures fluctuate on each stroke, consult the fault section before continuing.
- l) Connect the air supply to the gun; open the manual valves of each product; make a test projection and check the pressures on the product gages. If the projection test is correct and the pressures remain equal, proceed with the application



## SHUTDOWN PROCEDURES

Follow the recommended procedure in the indicated order for machine shut down when work is stopped for the day.

- a) Close the "RETRACT" valve (horizontal position).
- b) Close the manual valves at the bottom of the tanks.
- c) Use the gun to project into a waste container until the Isocyanate proportioning pump is in the retract position and the pressure begins to fall.

**CAUTION!** *To avoid possible product leakage and the early failure of the pump seals, the pressure must not be reduced to zero. It is recommended to keep the system with a minimum pressure of 30 bar (400 psi) to extend the life of the seals.*

- d) Turn the general switch "OFF". The temperature regulator will go out.
- e) Remove the contact thermometer and roll up the heated hoses.
- f) Close the manual valves on the coupling block and remove the gun to perform the corresponding maintenance.



## CLEANING

**CAUTION!** *The unit includes components that reach temperatures that are liable to cause burns. The hot parts of the unit must not be handled until they have cooled.*

To avoid possible contamination, the circuits of the unit must be flushed clean (pumps, heaters and hoses) whenever applications have to be made that require a change of components.

Follow the recommended procedures in the order indicated to perform the cleaning:

- a) Dismantle the gun and leave the coupling block connected to the hoses.
- b) Open the manual valves at the bottom of the tanks.
- c) Place 2 separate vessels under the coupling block to gather up the products contained inside the machine.
- d) Open the manual valves on the coupling block.
- e) Open the "RETRACT" valve (vertical position).
- f) Turn the general switch "ON". Using the air pressure regulators, turn anti-clockwise until the end.
- g) Push the "START" green button, the temperature regulator will light on, (whenever the switch of the heaters is in "On"), check the product pumps begin to slowly move.  
If necessary, increase the pneumatic pressure by turning the regulator clockwise.
- h) Allow the materials to come out of the coupling block until the tanks are empty.
- i) Close the manual valves on the coupling block.
- j) Turn the general switch "OFF". The temperature regulator will go out.
- k) Close the manual valves at the bottom of the tanks.
- l) Fill the component tanks using DOTP cleaning agent, about 5 liters each one.
- m) Open the manual valves at the bottom of the tanks.
- n) Place 2 separate vessels under the coupling block to gather up the DOTP contained inside the machine.
- o) Open the manual valves on the coupling block.
- p) Turn the general switch "ON".
- q) Push the "START" green button, the temperature regulator will light on, (whenever the switch of the heaters is in "On"). Check the product pumps begin to slowly move.
- r) Allow the materials to come out of the coupling block until the tanks are empty.
- s) Turn the general switch "OFF". The temperature regulator will go out.
- t) Close the manual valves at the bottom of the tanks.
- u) Fill the component tanks using new chemical product.
- v) Open the manual valves at the bottom of the tanks.
- w) Turn the general switch "ON".
- x) Push the "START" green button, the temperature regulator displays will light on, (whenever the switch of the heaters is in "On"). Check the product pumps begin to slowly move.  
If necessary, increase the pneumatic pressure by turning the regulator clockwise.
- y) Allow the products to come out until you see that only DOTP cleaning agent comes out free of impurities.



- z) When the products come out without the contamination produced by the effect of the DOTP cleaning agent, the cleaning process is complete and you can proceed as normal.
- aa) Close the "RETRATC" valve (horizontal position).
- bb) Turn the general switch "OFF". The temperature regulator displays will go out.
- cc) Close the coupling block and mount the gun.
- dd) Close the manual valves at the bottom of the tanks.
- ee) Follow the Start up Procedures if change the chemical products.



## LONG-TERM SHUTDOWN PROCEDURES

**CAUTION!** *The unit includes components that reach temperature that are liable to cause burns. The hot parts of the unit must not be handled until they have cooled.*

When you plan to shut down the machine for more than FOUR weeks, the products contained in the machine must be replaced by DOTP plasticizing agent.

Follow the recommended procedures in the order indicated:

- a) Place two drums of DOTP cleaning agent close to the machine.
- b) Dismantle the gun and leave the coupling block connected to the hoses.
- c) Place 2 separate vessels under the coupling block to gather up the products contained inside the machine.
- d) Open the manual valves on the coupling block.
- e) Open the manual valves at the bottom of the tanks.
- f) Open the "RETRACT" valve (vertical position).
- g) Turn the general switch "ON". Using the air pressure regulators, turn anti-clockwise until the end.
- h) Push the "START" green button, the temperature regulator will light on, (whenever the switch of the heaters is in "On"). Check the product pumps begin to slowly move.  
If necessary, increase the pneumatic pressure by turning the regulator clockwise.
- i) Allow the materials to come out of the coupling block until the tanks are empty.
- j) Turn the general switch "OFF". The temperature regulator will go out.
- k) Close the manual valves at the bottom of the tanks.
- l) Fill the component tanks using DOTP cleaning agent, about 5 liters each one.
- m) Open the manual valves at the bottom of the tanks.
- n) Turn the general switch "ON".
- o) Push the "START" green button, the temperature regulator will light on, (whenever the switch of the heaters is in "On"). Check the product pumps begin to slowly move.
- p) Turn the general switch "OFF". The temperature regulator will go out.
- q) Close the "RETRATC" valve (horizontal position).

**CAUTION!** *To avoid possible product leakage and the early failure of the pump seals, the pressure must not be reduced to zero. It is recommended to keep the system with a minimum pressure of 30 bar (400 psi) to extend the life of the seals.*

*The proportioning pumps, the heaters and the hoses must be full of DOTP plasticizing oil. Never leave the machine or the hoses empty of product or DOTP plasticizing oil.*

**NOTE:** *Never use liquids not recommended or not approved by HI-TECH. Never use approved liquids that have been contaminated with water or ISO/POL. If you are not sure in the quality of the liquid you are going to use we strongly recommend that you check the machine 2-3 times every 2 weeks after you have filled it by recirculating through heated hoses (see p.34) and/or hoses with recirculation (see p.25) with fresh plasticizer unless you make sure the liquid that comes out is completely pure and clean.*



## TROUBLESHOOTING

The **Easy Spray** unit has been designed and built to withstand severe working conditions with a high degree of reliability, provided it is used suitably. This chapter contains information on possible faults that may prevent the continuation of work with the unit. The information provided must serve as guideline to detect and resolve the large majority of the problems before calling for the assistance of the authorized distributor or **HI-TECH** technical service. In any case, feel free to contact the technical assistance service of **HI-TECH SPRAY EQUIPMENT, S.A.** where a qualified technician will advise you on whatever you may need.

**NOTE:** All repairs performed by unqualified personnel or the use of spares other than originals may cause damage to the unit and put the operator at risk.



*To prevent possible bodily harm caused by incorrect handling of the raw materials and solvents used in the process, carefully read the safety information provided by your supplier.*

*Deal with the waste caused according to current regulations.*



*Disconnect the unit from the power supply before carrying out any operation inside the electrical console.*

*The electrical maintenance of the machine must only be performed by a qualified electrician.*



*To avoid damage caused by the impact of pressurized fluids, do not open any connection or perform maintenance work on components subject to pressure until the pressures have been completely eliminated.*



*Use suitable protection when operating, maintaining or remaining in the operating area of the unit. This includes, but is not limited to, the use of face masks, protective goggles, gloves, shoes and safety clothing.*

*The unit includes components that reach temperature that are liable to cause burns. The hot parts of the unit must not be handled until they have cooled.*



*To prevent serious harm by crushing or loss of limbs, do not work with the unit without the safety duly installed on all moving parts. Make sure that all of the safety protections are correctly fitted after all repair or maintenance work.*

## Heaters

**WARNING!** Before resolving any kind of defect, make sure all of the pushbuttons are off, that the general switch is in shutdown position and that the unit is disconnected from the power supply. Never handle the inside of the control panel with the unit connected to the main power supply. The heaters are components that reach high temperatures; wait until they have cooled before handling.

**NOTE:** The thermostat is a safety element in contact with the heater. If the temperature exceeds 120° C (248° F) the thermostat will cut off the electric supply by deactivating the POWER CONTROL. The thermostat will not reset until the temperature in the heater is below 120° C (248° F).


### 1. Heating Elements

Each heater includes two 900 W heating elements connected in parallel, which give the system a total power of 1800 W. If under normal conditions of room temperature it is not possible to reach the required temperature in two or three minutes, it is possible that several heating elements are not working.

To check the state of the elements, proceed as follows:

To check the state of the element, proceed as follows:

With the main switch off check with a tester that reading the total value of the heater resistance is indicated in the table according to the power, voltage and number for each installed heater elements, a higher value would indicate that one or more elements are faulty .





Disconnect them and check that the individual value of each element is as shown in the table according to the installed power and voltage.

**Table 2. Elements Values List**

(W)	(V)	x1 ( $\Omega$ )	x2 ( $\Omega$ )	x4 ( $\Omega$ )	x6 ( $\Omega$ )
450	230	117 $\pm$ 2	58 $\pm$ 2	29 $\pm$ 2	19 $\pm$ 2
900	230	58 $\pm$ 2	29 $\pm$ 2	14 $\pm$ 2	9 $\pm$ 2
900	400	177 $\pm$ 2	88 $\pm$ 2	44 $\pm$ 2	29 $\pm$ 2
1250	230	42 $\pm$ 2	21 $\pm$ 2	10 $\pm$ 2	7 $\pm$ 2
1250	400	128 $\pm$ 2	64 $\pm$ 2	32 $\pm$ 2	21 $\pm$ 2
1250	440	154 $\pm$ 2	77 $\pm$ 2	38 $\pm$ 2	25 $\pm$ 2
1500	230	35 $\pm$ 2	17 $\pm$ 2	8 $\pm$ 2	5 $\pm$ 2
1500	400	106 $\pm$ 2	53 $\pm$ 2	26 $\pm$ 2	17 $\pm$ 2
1500	440	129 $\pm$ 2	64 $\pm$ 2	32 $\pm$ 2	21 $\pm$ 2
1800	230	29 $\pm$ 2	14 $\pm$ 2	7 $\pm$ 2	4 $\pm$ 2
1800	400	88 $\pm$ 2	44 $\pm$ 2	22 $\pm$ 2	14 $\pm$ 2
1800	440	107 $\pm$ 2	53 $\pm$ 2	26 $\pm$ 2	17 $\pm$ 2
2000	230	26 $\pm$ 2	13 $\pm$ 2	6 $\pm$ 2	4 $\pm$ 2
2000	400	80 $\pm$ 2	40 $\pm$ 2	20 $\pm$ 2	13 $\pm$ 2
2000	440	96 $\pm$ 2	48 $\pm$ 2	24 $\pm$ 2	16 $\pm$ 2

Under extreme environmental conditions, the heater might be affected and fail to reach the required temperature. In this case, put the unit in a more favorable place, or use an auxiliary heating system.

## 2. Automatic Switch

This protects the elements against any possible change in voltage. With the general switch turned off, open the control panel and make sure the switch is activated (see electrical diagram), otherwise activate it.

## 3. Temperature

The temperature regulator automatically detects any fault in the operation of the temperature probe. The device display “- - - -”.

If the fault occurs, replace the probe, paying special attention not to damage it when assembling. The probe must be in firm physical contact with the element.



## Hose Heating (Optional)

**WARNING!** Before resolving any kind of defect, make sure all of the pushbuttons are off, that the general switch is in shutdown position and that the unit is disconnected from the power supply source. Never handle the inside of the control panel with the unit connected to the power supply. The hoses can reach high temperatures; wait until they have cooled before handling.

Follow the recommended procedure in the order indicated, to try to solve the problem and avoid costly repairs. Make sure all the automatic switches and control elements are in the correct working position before determining the existence of a fault.

### PROBLEMS

The hose is hot, but fails to reach the selected temperature.  
The hose is not hot.  
Only the sections of the hose closest to the unit are heated.  
The automatic switch trips.

### SOLUTIONS

1-2  
2-3-4-5  
5  
3

### SOLUTIONS

#### 1. Hose Length

The **Easy Spray** has been designed to work with a maximum hose length of 48 meters /160 ft. A longer length will render the heating capacity less effective. Under extreme environmental conditions, the hose heating system may be affected and fail to reach the required temperature.

#### 2. Hose Transformer

The transformer offers the option of connecting to a 40 V output voltage valid for the connection of hose sections with a total length of up to 48 meters. If the connection is performed incorrectly, the hoses will not reach the required temperature. On the transformer display appears (00).

The hose connection system includes special terminals (fast lock) to facilitate the electrical connection to the transformer and between the different sections installed in the unit.

#### 3. Automatic Switch

This protects the secondary circuit of the transformer. The switch is located on the front of the transformer; make sure it is turned on, otherwise turn it on. Replace it with one of an equal amperage if the switch fails to work correctly. If the automatic switch is not working; on the transformer display appears (00).

**CAUTION!** The replacement of the automatic switch with another of different characteristics may cause damage to the equipment and put the operator at risk.

#### 4. Triac

This determines that the triac is faulty when all of the previous checks have been correct. Replace the triac if it fails to work correctly.



### 5. Hose Heating Components

With the general switch turned off, make sure the hose connectors and the electrical connections between the hoses and the unit are correct and well fixed. If the connections are correct and the hoses do not heat up, check section by section to locate the connection that is failing.

Proceed as in the following:

- a) Disconnect the unit from the power supply by deactivating the general switch and start to check the hose section closest to the gun. Remove the "Fast Lock" connector, and make a "bridge" on the connection immediately before.
- b) Restore the power supply, press the POWER CONTROL key and the key under the HOSES display. If the heating works, the problem will be in the last section of hose. Replace it. If not, do the following.
- c) Disconnect the unit from the power supply, remove the "Fast Lock" connector from the last section of hose and make a "bridge" on the connection immediately before.
- d) Restore the power supply, press the POWER CONTROL key and the key under the HOSES display. If the heating works, the problem will be in the last but one section of hose. Replace it. If not, repeat steps c) and d) until you find the point of the fault
- e) The display located on the transformer allows seeing the amps. Turn clockwise to increase the amps and anti-clockwise to reduce it. The value of the power must be set between 0 and 50 Amps.



## Proportioning Pumps

**WARNING!** Before resolving any kind of defect, make sure all of the pushbuttons are off, that the general switch is in shutdown position and that the unit is disconnected from the power supply source. Never handle the inside of the control panel with the unit connected to the power supply. The hoses can reach high temperatures; wait until they have cooled before handling.

### PROBLEMS

### SOLUTIONS

The pumps fail to maintain the pressure when the unit is shut down.	1
There are pressure differences between the proportioning pumps.	1-2-3
There is cavitation in the proportioning pump.	1-2-3
The proportioning pumps do not change direction.	4
The proportioning pumps fail to move and the direction indicator lights are out.	4
The movement of the proportioning pumps is erratic.	4
Difference of pressure or speed in the up stroke against the down stroke.	5

### SOLUTIONS

#### 1. Loss in the Ball Checks

Check the pressure gauges to identify which pump is not maintaining pressure. To determine which ball valve is failing, check in which displacement direction the pump is losing pressure. If pressure is lost in an ascending direction, check the discharge ball valve (upper valve), if pressure is lost in a descending direction, check the aspiration ball valve (lower valve).

Proceed as follows to check the ball checks:

- Disconnect the machine from the power supply and close all supply valves and the supply system to the transfer pumps.
- Depressurize the proportioning pump and remove the corresponding ball check.
- The loss from the ball checks is usually caused by foreign particles that prevent the perfect coupling of the ball in the housing at the top of the closing bushing. Clean the ball and the seat of the bushing and make sure there are no faults from nicks, marks or scratches to the bushing or the ball. If cleaning fails to resolve the problem or any fault is observed, replace the bushing and the ball.

#### 2. Unbalanced Pressures

Pressures are unbalanced when there is an obstruction in the hose or in the gun that prevents one of the components from leaving freely through the gun chamber when it is projected, or when a problem in the pumping system prevents one of the components reaching the gun in the required amount.

To identify which component is relatively easy if we bear in mind that the chemical components used in the polyurethane foaming are of a different color. By observing the color of the material that leaves the gun, we can determine which component is missing.



To determine whether the unbalance is caused as a result of an obstruction or as a consequence of a problem in the pumping system, project with the gun, observe the pressure indicated on the corresponding pressure gage to the missing component and compare it with the pressure indicated by the gage to the other component: if the pressure of the missing component is higher, the unbalance is the result of an obstruction, if the pressure is lower, the unbalance is the consequence of a problem in the pumping system.

### 3. Cavitation

Cavitation occurs when the proportioning pump requires a larger volume of material than that supplied by the feeding system, causing the formation of a vacuum in the proportioning pump. The causes of cavitation are the following:

- a) High viscosity: the polyurethane foaming systems normally require a minimum transfer temperature of 12° C; at lower temperatures, the product increases in viscosity, making the pumping more difficult. When the ambient conditions prevent the products from being maintained at a minimum temperature of 12° C auxiliary heating elements must be used to condition the products as the minimum temperature required for the transfer.
- b) The product inlet filter is obstructed (see Maintenance).
- c) The inlet ball valve has leaks as a result of wear or possible faults in the ball or the closing surface of the bushing, which means that part of the material supplied returns to the supply tank and that the proportioning pump supplies a smaller volume of material in the discharge cycle, causing an incorrect ratio.

### 4. Fault in the Direction Change Micro

The pneumatic cylinder that drives the supply pumps has two magnetic position detectors for making the change of direction. Each detector includes an led to indicate when it is active. Any accidental movement of the detection position will prevent the pumps from making the change in direction, which will oblige the detector to be put back into the correct position by using the gauge supplied with all accessories.

## MAINTENANCE

To achieve maximum output from the **Easy Spray** unit, certain daily or regular maintenance operations are needed.



*To prevent all possible body harm caused by incorrect handling of the raw materials and solvents used in the process, carefully read the safety information provided by your supplier.*

*Deal with the waste caused according to current regulations.*



*Disconnect the unit from the power supply before carrying out any operation inside the electrical console.*

*The electrical maintenance of the machine must only be performed by a qualified electrician.*



*To avoid damage caused by the impact of pressurized fluids, do not open any connection or perform maintenance work on components subject to pressure until the pressures have been completely eliminated.*

*Use suitable protection when operating, maintaining or remaining in the operating area of the unit. This includes, but is not limited to, the use of masks, protective goggles, gloves, shoes and safety clothing.*



*The unit includes components that reach temperature that are liable to cause burns. The hot parts of the unit must not be handled until they have cooled.*



*To prevent serious harm by crushing or loss of limbs, do not work with the unit without the safety duly installed on all moving parts. Make sure that all safety protections are correctly fitted after all repair or maintenance work.*



## Heaters

**WARNING!** Before performing any maintenance work, make sure all of the pushbuttons are off, that the general switch is in shutdown position and that the unit is disconnected from the main power supply source. Never handle the inside of the control panel with the unit connected to the power supply. The heater is a component that reaches high temperatures; wait until it has cooled before handling.

### 1. Heating Elements

To replace a faulty element, proceed as followings:

- a) Depressurize the unit, disconnect it from the power supply and remove the cover on the heater.
- b) Disconnect the element from the terminal block with an appropriate spanner, loosen the element and remove it from its housing. Inspect the element; it must be smooth and shiny in appearance. If it is blackened or has material adhered to it, replace the element.
- c) Check the new element with a tester: the reading of the value of the resistance must be as shown in **Table 2** on **pag.39**.
- d) Apply Teflon or sealing paste to the thread and screw the element into its housing.
- e) Reconnect the wires to the connection block; make sure the connection is in parallel and fit the heater cover.

**NOTE:** If the element that has to be replaced is the one in contact with the temperature probe, first remove the probe.

### 2. Temperature Probe

The temperature probe is fixed to the connector with a ferule and a torque nut. Once inserted in its housing, the ferule forms part of the probe and does not allow it to be relocated or moved. The location of the probe is very important and must be done correctly before fitting the torque nut.

- a) Depressurize the unit and disconnect it from the power supply. Check the torque of the body of the connector inserted in the heater to prevent leaks.
- b) Install the heating element.
- c) Insert the torque nut and the ferule in the probe and insert this in the connector body until it comes into positive contact with the heating element. Make sure the spring does not prevent the probe from making contact with the element.
- d) Fix the probe in place and fit the torque nut.



## Proportioning Pumps

***WARNING!*** Before proceeding with maintenance works, make sure that all push buttons are switched off, the general switch is in the off position, and the Unit is unplugged from the power supply. Never handle the control panel interior while the Unit is plugged into the electricity grid. Dosing pumps are components that work under pressure, do not open any connections or perform any repair or maintenance work on components submitted to pressure until all pressures have been completely released.

When the pump works properly, it is not uncommon for a small amount of resin to filter through the joints and reach the visible part of the pump axis. Periodically inspect the axis and clean the residue when dosing pumps are stationary and the machine is switched off.

Disassemble and clean the dosing pumps annually, despite no obvious signs of leaks. Use this time to completely replace the joints and bearings given that, if you reassemble an element that does not seem damaged, it can cause premature wear in the remaining components (the NR-00045 Components Manual includes the joint kits that correspond to each pump model and size). Pump distribution bases must also be inspected, checking that the ball valves show no signs of wear, dents or marks that affect the pump's proper operation.

Perform a daily inspection of the Isocyanate pump lubrication bowl and check the condition of the DOTP plasticiser oil it contains. Replace the oil when you observe colour changes or when it shows signs of solidification. If this circumstance persists, replace the isocyanate pump joints using the corresponding kit.

In cases where the machine is submitted to large workloads or special work conditions, disassemble, clean and replace the dosing pump joints every six months.

Inspect rods, pistons and inside the sleeves for marks or scratches that may cause leaks or premature damage to the joints.

Only qualified personnel will be authorised to replace dosing pump joints, since they have the required expertise to that effect.

To assemble the pump, there are specific tools that prevent damage to the seal lips of both the piston and the cylinder head.




First, assemble the rod set with the piston and all its components. Ensure that the piston seal lips are facing upwards.

Insert the assembled piston set inside the sleeve with the specific tool (1) (see **Table 3** on page 48).



Once you have inserted the piston into the sleeve, you must assemble the cylinder head seal. First place the seal funnel tool (2).



Next, place the cylinder head seal with the lips facing downwards.



Subsequently, you must place and fasten the tool (3) to the sleeve and insert the plunger (4) inside the rod. Screw as far as it will go.

Remove all the tools and finish the pump assembly by placing the guide with its joint, and fastening the piston and the nut with the bowl.

**Table 3. List of Tools**

	Tool (1)	Tool (2)	Tool (3)	Tool (4)
Size				
#4,5	HT-00034	HT-00116	HT-00119	HT-00121
#7,6	HT-00031	HT-00117	HT-00120	HT-00122

**Note: These tools not supplied with the machine, they are optional parts on request.**



### ***Inlet supply filters***

The filter bodies have a filter screen that prevents solid particles from entering the unit. Inspect the filters each day as part of the machine start-up, and clean them. Replace the filter screen if necessary.

Isocyanate is a product that crystallizes with ambient moisture or freezing. If the storage and transfer is correct and the operating procedures are respected, the risk of contamination of the Isocyanate filter will be minimized.

***NOTE: Clean the Isocyanate inlet filter before the daily start-up; it should not be cleaned after the machine has been stopped for the day. Immediately beginning to project after cleaning the filter reduces the risk of absorption of moisture and the possibility of contamination through the reaction with the solvent used in the cleaning operation.***

To check the product inlet filters, proceed as follows:

- a) Disconnect the unit from the power supply and close the inlet ball valve from the filter you wish to check.
- b) Place a suitable vessel under the filter to collect the product coming out on removal. Carefully loosen the filter stopper to allow the product to be emptied into the vessel below. Completely unscrew the stopper.
- c) Remove the seal, the spring and the mesh and clean it all with the solvent used for cleaning the gun. Dry it all and check that the mesh is not obstructed. The holes in the mesh must be completely free. Replace the mesh if more than 10% of the surface is obstructed.
- d) Refit the mesh, the spring and the seal. Screw on the stopper.
- e) Open the product entry valve of the filter, make sure there are no leaks and proceed with the normal operation.



## ***Isocyanate pump lubrication system***

Each day, inspect the lubrication cup of the Isocyanate pump and check the state of the DOTP plasticizing oil. Replace the oil when it shows changes in color or signs of solidification.

The DOTP oil solidifies as a result of the absorption of moisture and the maintenance interval will depend on the working conditions.

The oil discoloration is due to the small film of Isocyanate that lies on the pump shaft during the pumping operation. If the gaskets and the seals are in a good state, the plasticizing oil will not have to be changed so frequently.

To replace the plasticizing oil of the pump, proceed as follows:

- a) Use the gun to project until the Isocyanate proportioning pump is at the highest point of the rising run. Press the NORMAL key to interrupt the working cycle. The pushbutton led will go out.
- b) Press the POWER CONTROL key and turn the general switch to OFF. Disconnect the machine from the power supply.
- c) Remove the existing DOTP oil from the cup, clean the cup and the shaft of the pump, eliminating any remain power supply of polluted oil or crystallized material. Use a wooden or plastic tool to clean the shaft. Fill the cup with new DOTP plasticizing oil.



## CONTENTS

<b>Warranty</b>	<b>2</b>
<b>Safety and Handling</b>	<b>3</b>
<b>Characteristics</b>	<b>6</b>
Principal Heating System	6
Proportioning Pumps	6
Recirculation System	7
Proportioning System (OPTIONAL)	7
<b>Technical Specifications Easy Spray-100</b>	<b>8</b>
Electrical	8
Mechanical	8
Acoustic	8
<b>Technical Specifications Easy Spray-200</b>	<b>9</b>
Electrical	9
Mechanical	9
Acoustic	9
<b>General Description</b>	<b>10</b>
<b>Control Panel and Hose Heated System</b>	<b>13</b>
<b>Regulator of Temperature Heaters</b>	<b>15</b>
<b>Method of Threaded Union of the Hoses</b>	<b>18</b>
<b>Generic Installation</b>	<b>19</b>
<b>Installation (Recirculation Unit)</b>	<b>20</b>
<b>Start-Up Procedures</b>	<b>23</b>
<b>Daily Shutdown</b>	<b>24</b>
<b>Cleaning</b>	<b>25</b>
<b>Shutdown Procedures</b>	<b>27</b>
<b>Installation (Heated Hoses Unit)</b>	<b>29</b>
<b>Start UP Procedures</b>	<b>32</b>
<b>Shutdown Procedures</b>	<b>33</b>
<b>Cleaning</b>	<b>34</b>
<b>Long-Term Shutdown Procedures</b>	<b>36</b>
<b>Troubleshooting</b>	<b>37</b>
Heaters	38
Hose Heating (Optional)	40
Proportioning Pumps	42
<b>Maintenance</b>	<b>44</b>
Heaters	45



Proportioning Pumps	46
Inlet supply filters	49
Isocyanate pump lubrication system	50
<b>Contents</b>	<b>51</b>
<b>List of Illustrations</b>	<b>52</b>
<b>List of Tables</b>	<b>52</b>

## LIST OF ILLUSTRATIONS

Figure 1. General Description Easy Spray	10
Figure 2. Control Panel and Hose Heating	13
Figure 3. Method of union of the Hoses	20

## LIST OF TABLES

Table 1. Tightening Threaded Joints	18
Table 2. Elements Values List	39
Table 3. List of Tools	48